

**Express Vacuum**  
**CE EAC**  
**Instruction Manual**  
**RoHS2 Compliant**  
**Important Safety Instructions**

When using an electrical appliance, basic precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE**  
**WARNING:**  
**TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:**

1. Do not leave appliance plugged in. Unplug from outlet when not in use and before servicing.
2. Do not use outdoors or on wet surfaces, any wet material or in a wet environment.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual. Use only manufacturer's recommended attachments.
5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped in water, return to a service center.
6. Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
10. Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
11. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
12. Do not use without vacuum bags and/or filters in place.
13. Turn off all controls before unplugging.
14. Use extra care when cleaning on stairs.
15. Do not use to pick up any liquids, flammable or combustible, such as gasoline, or use in areas where they may be present.
16. Connect to a properly grounded outlet only.
17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

**GROUNDING INSTRUCTIONS:**

This appliance must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

**WARNING:**

Improper connection of the equipment-grounding conductor can result in electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug. No adapter should be used with the plug. The Express is for use on a nominal 120-volt 50/60Hz. Circuit. 230V Optional.

**OPERATING INSTRUCTIONS:**

The vacuum is packed with a cartridge filter, or a bag & bag holder filter. When it is time to change the filter, follow these simple instructions:

1. Unplug the vacuum from the power source.
2. Set the vacuum upright, resting on the back of the machine with the Inlet Door facing you.
3. With your thumb and forefinger, pull out the curved side tabs of the Inlet Door until they are free from the latching area of the body of the vacuum. Then pull the cover towards you. The cover will separate from vacuum body and the cartridge filter, or bag & shell filter can be changed.

4. Cartridge filter replacement-Install a new cartridge with the pleated paper end towards the motor. Note: The inlet hole in front of the canister filter is slightly off-center. It should be installed with the label facing the top of the vacuum.
5. Bag filter replacement-Insert new bag into the shell filter. Replace the shell filter once the inside of the shell filter is covered with debris. Insert shell filter with label facing up.
6. Replace the door, aligning it carefully, first the top, then the bottom. Press down firmly and evenly on the side tabs, pushing past the second notch.
7. Dispose of the filter cartridge in an appropriate manner compliant with all local, state, and federal laws.
8. These vacuums have a factory installed resettable Thermal Cutout (TCO) for added operator and motor safety. If the unit gets too hot, the vacuum will shut down for approx. 20 minutes. Turn the on/off switch to the off position, and turn back on in approximately 20 minutes. Your hose may be clogged, or it may be time to install a new filter.

Your Express Vacuum is covered by an 18 month limited warranty. Please contact your local distributor for further details. THANK YOU for choosing Atrix International, Inc.

**REPLACEMENT PART NUMBERS:**

710333	2 Pack of Standard Cartridge Filters	31661	6' Black Stretch Vacuum Hose, ESD safe
730333	2 Pack of HEPA Cartridge Filters	31671	10' Black Stretch Vacuum Hose, ESD safe
730300	10 Dust Bags & 1 Shell Filter	AVPA008	6' Clear Vacuum Hose
720200	10 Toner Bags & 1 Shell Filter	AVPA009	9' Clear Vacuum Hose
66021A	230V European Power Cord, 8'2"	730020	3' Black Hose
66097A	230V U.K. Power Cord, 8'2"	AVPA005	Hose End Plug
OVPE004B	110V Power Cord, 25'	410017	Orange Plug for Inlet Door
31651	110V Power Cord, 10'	730060	Carrying Bag, Deluxe, Oversized
31652	Crevice Tool – ESD safe	HT4626006	Carrying Bag, Economy
31654	Crevice Tool Brush	AVPA016	Shoulder Strap
31257	Flexible Gooseneck Tool, 12", ESD safe	UE7022BK	Straight Wand, 20"
31657	Flexible Gooseneck Tool, 16", ESD safe	32555	Micro Attachment Kit
31653	Oval Dusting Brush – ESD safe	AVPA011	Utility Nozzle
VAC31653	Round Dusting Brush	AVPA017	Utility Nozzle Brush
		ATIVACACC	Accessory Kit

View All Accessories and Vacuums at <http://www.atrix.com>



*The ULTRA FINE  
vacuum cleaner company!*

ATRIX INTERNATIONAL, INC. 1350 Larc Industrial Blvd. Burnsville, MN 55337-1412  
 952.894.6154 800.222.6154 Fax 952.894.6256  
[www.atrix.com](http://www.atrix.com)

To Register your Warranty  
 Visit: [www.atrix.com](http://www.atrix.com)

**Tonerstaubsauger Express**  
**CE EAC**  
**Bedienungsanleitung**  
**Wichtige Sicherheitshinweise**

Beim Gebrauch eines elektrischen Gerätes sollten stets grundlegende Sicherheitsvorkehrungen getroffen werden, unter anderem folgende:

**Lesen Sie diese Bedienungsanleitung sorgfältig durch, bevor Sie das Gerät in Betrieb nehmen. Beachten Sie alle nachstehenden aufgeführten Sicherheitshinweise. Halten Sie diese Bedienungsanleitung für den künftigen Gebrauch bereit.**

**WARNUNG:**

**Um die Gefahr eines Brandes, Elektroschocks oder einer Verletzung zu vermeiden:**

1. Das Gerät nicht unbeaufsichtigt lassen, wenn es an der Steckdose angeschlossen ist. Wenn das Gerät nicht genutzt wird und vor Wartungsarbeiten den Netzstecker ziehen.
2. Nicht im Freien, auf nassen Oberflächen oder Materialien oder in feuchter Umgebung einsetzen.
3. Dieses Gerät darf nicht als Spielzeug verwendet werden. Bei der Verwendung durch oder in der Nähe von Kindern ist größte Vorsicht geboten.
4. Benutzung nur gemäß Beschreibung. Nur die vom Hersteller empfohlenen Zubehörteile verwenden.
5. Nicht mit beschädigtem Kabel oder Stecker verwenden. Wenn das Gerät nicht ordnungsgemäß funktioniert, fallengelassen, beschädigt, im Freien gelassen oder in Wasser getaucht wurde, muss es zum Wartungseinsatz eingeschickt werden.
6. Das Gerät nicht am Kabel ziehen oder tragen. Das Kabel nicht als Tragegriff verwenden, es in einer Tür einklemmen oder um scharfe Ecken und Kanten ziehen. Das Gerät nicht über das Kabel laufen lassen. Das Kabel von heißen Oberflächen fernhalten.
7. Das Gerät nicht durch Ziehen am Kabel von der Steckdose trennen. Zum Herausziehen des Steckers am Stecker selbst ziehen, nicht am Kabel.
8. Den Stecker bzw. das Gerät nicht mit nassen Händen anfassen.
9. Keine Gegenstände in Öffnungen des Geräts einführen. Das Gerät nicht mit blockierten Öffnungen betreiben. Alle Öffnungen müssen frei von Staub, Fusseln, Haaren und anderen Gegenständen sein, die den Luftstrom behindern könnten.
10. Haare, lose Kleidungsstücke, Finger und andere Körperteile von Öffnungen und beweglichen Teilen fernhalten.
11. Es dürfen keine brennenden oder qualmenden Gegenstände aufgesaugt werden, wie z.B. Zigaretten, Streichhölzer oder heiße Asche.
12. Nicht ohne Staubbeutel oder Staubfilter verwenden.
13. Vor entfernen des Netzsteckers das Gerät ausschalten .
14. Bei der Reinigung auf Treppen ist besondere Vorsicht geboten.
15. Nicht zum Aussaugen von brennbaren und entzündlichen Stoffen verwenden, wie Benzin oder nicht in Bereichen verwenden , wo diese vorkommen können.
16. Nur an ordnungsgemäß geerdete Steckdosen anschließen.

## **Erdungsanweisungen**

Dieses Gerät muss geerdet sein. Sollte eine Fehlfunktion oder ein Versagen auftreten, wird durch die Erdung das Risiko eines Elektroschocks verringert. Das Gerät und das Kabel sind werkseitig mit einem Schutzkontaktstecker und Erdungsleiter ausgestattet. Der Netzstecker muss in eine geeignete Schutzkontaktsteckdose eingesteckt werden, die ordnungsgemäß und entsprechend allen örtlichen Vorschriften installiert und geerdet wurde.

### **WARNUNG:**

Nicht ordnungsgemäß angeschlossene Erdungsleiter kann die Gefahr eines Elektroschocks zur Folge haben. Wenden Sie sich an einen Elektriker oder Wartungstechniker, wenn Sie sich in Bezug auf die ordnungsgemäße Erdung der Steckdose im Zweifel sind. Der Netzstecker darf nicht modifiziert werden. Keine Verteilerdose verwenden.

Die Betriebsspannung für den Express Tonerstaubsauger beträgt 120 Volt 50/60 Hz, optional auch für 230 Volt 50/60 Hz erhältlich.

## **Bedienungsanleitung:**

Der Tonerstaubsauger wird mit einem Filterbehälter oder Filterhalter mit Filtertüte geliefert.

Wenn der Filter ausgewechselt werden muss, gehen Sie folgendermaßen vor:

1. Ziehen Sie das Netzkabel aus der Steckdose.
2. Stellen Sie den Staubsauger senkrecht auf, dass die vordere Abdeckung zu Ihnen zeigt.
3. Ziehen Sie mit Daumen und Zeigefinger die abgerundeten Seitenlaschen der vorderen Abdeckung heraus. Ziehen Sie die Abdeckung zu sich. Sie kann vollständig abgenommen werden, um den Filterbehälter oder Beutel auszuwechseln.
4. Auswechseln des Filterbehälters: Setzen Sie den neuen Behälter so ein, dass die gefaltete Papierseite zum Motor hin zeigt. Hinweis: Die Einlassöffnung an der Vorderseite des Filterbehälters befindet sich nicht genau in der Mitte. Der Filter muss so eingesetzt werden, dass das Etikett zur Oberseite des Staubsaugers zeigt.
5. Auswechseln der Filtertüten: Setzen Sie eine neue Filtertüte in den Filterhalter ein. Ersetzen Sie das Filtergehäuse, wenn die Innenseite mit Schmutz bedeckt ist. Setzen Sie das Filtergehäuse so ein, dass das Etikett zur Oberseite des Staubsaugers zeigt.
6. Setzen Sie die vordere Abdeckung wieder auf. Vorsichtig ausrichten, erst oben dann unten. Drücken Sie die Abdeckung fest an den Seitenlaschen nach unten.

Auf den Express Staubsauger wird vom Hersteller eine 18-monatige Garantie gegen Material- und Verarbeitungsfehler gegeben. Sollte es erforderlich werden, Garantieleistungen in Anspruch zu nehmen, wenden Sie sich an Ihren Fachhändler vor Ort, bei dem Sie das Gerät erworben haben. Danke, dass Sie Atrix International, Inc. gewählt haben.

**Ersatzteilenummern:**

710333	Standard Filterkartusche, 2er Pack	31661	Flexibler Saugschlauch, schwarz, (1,8 m)
730333	HEPA Filterkartusche, 2er Pack	31671	Flexibler Saugschlauch, schwarz, (3 m)
730300	10 Staubfiltertüten + Filtergehäuse	AVPA008	Saugschlauch, transparent (1,8 m)
720200	10 Tonerfiltertüten + Filtergehäuse	AVPA009	Saugschlauch, transparent (2,7 m)
66021A	230 V Netzkabel mit Schutzkontaktstecker, (2,5 m)	730020	3' Saugschlauch, schwarz, (0,9 m)
66097A	230 V UK Netzkabel, (2,5 m)	AVPA005	Schlauchendkappe
OVPE004B	110 V Netzkabel, (7,6 m)	410017	Verschlusskappe, orange
31651	110 V Netzkabel, (3 m)	730060	Tragetasche, Deluxe, XXL
31652	Schlitzdüse, antistatisch	HT4626006	Tragetasche, Economy
31654	Bürste für Schlitzdüse	AVPA016	Tragegurt
31257	Schwanenhalsdüse, antistatisch, (30 cm)	UE7022BK	Rohr, gerade, (50 cm)
31657	Schwanenhalsdüse, antistatisch, (40 cm)	32555	Mikro Zubehörteile, nicht antistatisch
31653	Ovale Staubbürste, antistatisch	AVPA011	Allzweckdüse
VAC31653	Runde Staubbürste	AVPA017	Bürste für Allzweckdüse
		ATIVACACC	Zubehörkit, nicht antistatisch

Registrieren Sie Ihre Garantie für Vakuum:  
Besuchen Sie: [www.atrix.com](http://www.atrix.com)