



**OMEGA GREEN SUPREME MRI VACUUM
INSTRUCTION MANUAL**

Model: VACOSMRI

UL, UL Canada, CE, TUV Approvals

Atrix

1350 Larc Industrial Blvd.

Burnsville, MN 55337

www.atrix.com

sales@atrix.com

Telephone: 952.894.6154

Toll Free Telephone: 800.222.6154

Fax: 952.894.6256

**Omega Green Supreme MRI Vacuum
For Models: VACOSMRI
UL, UL Canada, CE, TUV Approvals**

**Instruction Manual
Important Safety Instructions**

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

1. Do not leave appliance plugged in. Unplug from outlet when not in use and before servicing.
2. Do not use outdoors or on wet surfaces, any wet material or in a wet environment.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual. Use only manufacturer's recommended attachments.
5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped in water, return to a service center.
6. Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
10. Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
11. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
12. Do not use without vacuum filters in place.
13. Turn off all controls before unplugging.
14. Use extra care when cleaning on stairs.
15. Do not use to pick up any liquids, flammable or combustible, such as gasoline, or use in areas where they may be present.
16. Connect to a properly grounded outlet only.
17. *This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.*

Children should be supervised to ensure that they do not play with the appliance.

GROUNDING INSTRUCTIONS:

This appliance must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING:

Improper connection of the equipment-grounding conductor can result in electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug. No adapter should be used with the plug. The Omega is for use on a nominal 120-volt 50/60Hz. Circuit. 230V Optional.

OPERATING INSTRUCTIONS:

The vacuum is packed with the canister filter. When it is time to change the filter, follow these simple instructions:

1. Unplug the vacuum from the power source. Release front latches and open lid.
2. Lift filter out by placing fingertips under lifting tabs located on both ends of filter.
3. Push small orange filter plug into hose inlet to avoid any spills.
4. Dispose of the filter cartridge in an appropriate manner compliant with all local, state, and federal laws.
5. Insert new filter cartridge. Close lid and latch securely **PRIOR TO USE**.
6. These vacuums have a factory installed resettable Thermal Cutout (TCO) for added operator and motor safety. If the unit gets too hot, the vacuum will shut down for approx. 20 minutes. Turn the on/off switch to the off position, and turn back on in approximately 20 minutes. Your hose may be clogged, or it may be time to install a new filter.

Your Omega GREEN Supreme MRI Vacuum is covered by a 36 month limited warranty. Please contact your local distributor for further details. **THANK YOU** for choosing Atrix International, Inc.

REPLACEMENT PART NUMBERS:

<u>Description</u>	<u>Part No.</u>
Single Pack HEPA Filter	OF612HE
Single Pack ULPA Filter	OF712UL
2 Pack of Standard Dust, Dirt Debris Filters	31700-2P
Detachable 10' Power Cord (110V)	31651*
Detachable 25' Power Cord (110V)	OVPE004B
230V European Power Cord, 8'2"	66021A*
230V U.K. Power Cord, 8'2"	66097A*
ESD Safe Oval Dusting Brush	31653
ESD Safe Crevice Tool	31654
ESD Safe Flexible Gooseneck Crevice Tool, 16"	31657
15' Non-Metallic ESD Safe Hose	31690
20' Non-Metallic ESD Safe Hose	31692
Shoulder Strap	AVPA016*
Carrying Bag for 15' ESD Safe Hose	HT4626006*
Carrying Bag for 20' ESD Safe Hose	730060*
*Contains small amount of magnetism and should be kept out of the MRI room.	

Please contact Atrix for appropriate replacement parts: 1-800-222-6154,
www.atrinx.com, Email: Sales@atrinx.com

*****CAUTION:WARNING*****

As with ANY product used in an MRI environment, extreme care and caution must be used. The Atrix Omega Green Supreme MRI Vacuum does have some metal in the vacuum and power cord, but NO metal in the hose and hose attachments. Keep the vacuum as far away from the MRI machine as possible. This vacuum has included a 15' non-metallic hose as standard equipment for this very reason. A 20' optional non-metallic hose is also available. When possible, keep the vacuum outside of the MRI room. When possible, have another technician hold the vacuum for the operator during use.

Omega Green Supreme MRI Vacuum WARRANTY INFORMATION

Warranty/Service Information: For warranty service information, please contact your local distributor.

Omega Green Supreme MRI Vacuum Limited Warranty: To the original user purchasing these stated models, Atrix warrants that the vacuums will be free of defects in material and manufacture for a period of three (3) years from the date of purchase. Should any failure to conform to this warranty appear within this period, Atrix will, at its option, repair or replace the defective product. When using the standard Atrix filter for removing toner, developer, dirt, dust and other NON-hazardous waste, the vacuum can be serviced. It is the user's responsibility to return the product, freight prepaid, to Atrix International. When using the Atrix HEPA or ULPA filter for removing lead or other hazardous waste, the vacuum CANNOT be serviced. Field replacement parts will be made available to the user for the duration of the warranty period. These remedies are the user's exclusive remedies for breach of this warranty.

Exclusions to warranty coverage: The above warranty will not apply to any special configurations or to any units that have been modified, or damaged by negligence, misuse, accident or failure to follow Atrix's Instruction Manual. Consumable supplies, such as filters, accessories, and motor brushes are not covered by this warranty.

Disclaimer of Warranty: EXCEPT FOR THE IMPLIED WARRANTIES OF TITLE AND AGAINST PATENT INFRINGEMENT, ATRIX MAKES NO OTHER WARRANTIES WITH RESPECT TO THE ATRIX OMEGA PLUS AND OMEGA SUPREME PLUS SERIES VACUUM CLEANER, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limitation of Liability: ATRIX WILL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY COINCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR ECONOMICAL LOSS, BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR ANY OTHER LEGAL THEORY, EVEN IF ATRIX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE, EQUIPMENT USE, DATA OR INFORMATION OF ANY KIND. THE LIABILITY OF ATRIX SHALL NOT UNDER ANY CIRCUMSTANCE, EXCEPT AS EXPRESSLY PROVIDED HEREIN, EXCEED THE PRICE OF THE ATRIX OMEGA GREEN SUPREME MRI VACUUM.

To Register Your Warranty

Visit: <https://atrix.com/product-registration/>