

ATRIX

Barrel Vacuum Owner's Manual

Model: ATIH55-3

120V, 15A, 500W Motor x 3

**Arix International, Inc.
1350 Larc Industrial Blvd. Burnsville, MN
55337**

www.atrix.com

**952.894.6154 Tel
800.222.6154 Toll Free 952.894.6256 Fax**

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING APPLIANCE

WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY:

- Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- Electrical shock may occur if used outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended instructions.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to Atrix International.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges of corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers and all body parts away from openings and moving parts.
- Do not pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.
- Do not use without filter in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
- *This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.*

Children should be supervised to ensure that they do not play with the appliance.

GROUNDING INSTRUCTIONS

This appliance is Double Insulated. Double insulation protects the user of this appliance from an electrical shock by preventing any possibility of the external casing becoming live (the live wire cannot touch the casing even if wires inside become loose), thus eliminating the need for an earth connection.

IMPORTANT INSTRUCTIONS

Never use this appliance near flammable, explosive, hazardous or toxic substances: sparks from the motor could cause dangerous reactions.

Always unplug the appliance from the electrical outlet when leaving the appliance unattended or before attempting any repair.

**THIS APPLIANCE IS INTENDED FOR
COMMERCIAL USE ONLY.
SERVICING, OTHER THAN NORMAL
MAINTENANCE, MUST BE DONE BY
A QUALIFIED SERVICE
REPRESENTATIVE.**

Operation

This appliance is a commercial vacuum designed for dry pick up only. The motors can run simultaneously or independently as the job requires. This appliance is designed to sit on top of a standard 55-gallon steel drum.

Filter Changing and Maintenance

Turn off the motor switches and allow the motor to stop running. Unplug the unit. Remove the motor head from the barrel/drum adapter. Loosen the screws and remove the filter holder/retainer and remove the filter assembly.

Gently remove the Polyester Pretreated filter and shake out and blow off accumulated dust and debris. If necessary, you can gently rinse the dirt from the bag with water to provide a more thorough clean. Make sure it is dry before reapplying.

For any dust that is in the MAIN HEPA filter pleats, gently tap on the side of the drum to remove loose dust and debris. You may also use low volume compressed air to gently blow the dust away and out of the pleats.

When your Polyester Pretreated filter or the MAIN HEPA filter becomes too dirty or if they are damaged in any way, please replace with new.

Barrel Vacuum REPLACEMENT PARTS

<u>Description</u>	<u>Part No.</u>
3 Motor Vacuum Head	ATIBV55-MH
Barrel Drum Adapter	ATIBV55-DA
Premotor HEPA Filter Cartridge, MAIN	ATIBCVH1
Polyester Pretreated Filter for MAIN HEPA Filter	ATIBCVSF
12' Hose w/Ends	ATIBV55-12
3 Piece Chrome Wand Set	ATIBV55-WS
Floor Tool	ATIBV55-FT
55 Gallon Drum	ATI55-DRUM
Barrel/Drum Roller Base	ATIBV55-RB
25' Hose w/Ends	ATIBV55-25

Barrel Vacuum WARRANTY INFORMATION

Warranty/Service Information: For warranty service information, please contact Atrix.

Barrel Vacuum Limited Warranty: To the original user purchasing this Barrel Vacuum, Atrix warrants that the vacuums will be free of defects in material and manufacture for a period of one (1) year from the date of purchase. Should any failure to conform to this warranty appear within this period, Atrix will, at its option, repair or replace the defective product. These remedies are the user's exclusive remedies for breach of this warranty.

Exclusions to warranty coverage: The above warranty will not apply to any special configurations or to any units that have been modified, or damaged by negligence, misuse, accident or failure to follow Atrix's Instruction Manual. Consumable supplies, such as filters, accessories, and motor brushes are not covered by this warranty.

Disclaimer of Warranty: EXCEPT FOR THE IMPLIED WARRANTIES OF TITLE AND AGAINST PATENT INFRINGEMENT, ATRIX MAKES NO OTHER WARRANTIES WITH RESPECT TO THE BARREL VACUUM, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limitation of Liability: ATRIX WILL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY COINCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR ECONOMICAL LOSS, BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR ANY OTHER LEGAL THEORY, EVEN IF ATRIX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE, EQUIPMENT USE, DATA OR INFORMATION OF ANY KIND. THE LIABILITY OF ATRIX SHALL NOT UNDER ANY CIRCUMSTANCE, EXCEPT AS EXPRESSLY PROVIDED HEREIN, EXCEED THE PRICE OF THE BARREL VACUUM.